



HOW TO UNROOT

NOTES

1-This thing will factory reset the phone and remove ALL FILES ON THE PHONE

2-It will NOT remove files from SD-CARD

3-It will Lock your Device Bootlaoder RELOCK

See if your phone is cdma-gsm

lets say your phone is cdma

1-Google for HTC EVO 3D CDMA ICS RUU

2-Then google for HOW TO EXTRACT ROM FILE FROM RUU

3-Rename the ROM.ZIP (u will get from step 2) to PG86IMG

4-Open the BOOT LOADER Re inseart battrey then hold the volume down and power button

5-Go to FASTBOOT

6-Connect the Device to the PC

7-Make sure it says FASTBOOT USB

8-Download FASTBOOT-ADB From the description

9-Open the ADB FOLDER

10-Hold the SHIFT And Click Right mouse button

11-Select Open Command window Here

12-Type This command Fastboot OEM LOCK

13-Wait till phone reboots (or re-insert the battery)

14-Copy the PG86IMG we got from Step 3 And paste in root of SD-CARD (NOT IN FOLDER)

15-Open the Boot loader Again (From step 4)

16-Wait Till Loading complete

if error came then redo step 4

17-Click the Volume up button when it asks

18-What till Flashing the STOCK ICS ROM completes

Same thing for GSM versions but u need to search for the exact phone

Example:HTC EVO 3D GSM ICS ASIA

Example:HTC EVO 3D GSM ICS Europe

Example:HTC EVO 3D GSM ICS Arabic

Written By Ananjaser1211

For Rooting guid

Go to my channel

Ananjaser1211

See for HOW TO ROOT HTC EVO 3D