

How to Read and Understand Rim Size Labelling



Confused about rim size markings? This article will answer all your questions and teach you <u>How to</u> <u>Read and Understand Rim Size Labelling</u>. When reading rim size labelling, you need to find the width, diameter, offset, and backspacing measurements.

You can find those measurements on the rim markings or by measuring them yourself. Once you have them, finding the correct-size rims for your car will be a breeze.

Understanding your rim size is crucial for several reasons, such as fitting rims onto your car and choosing the correct size tyres for them. So, we'll look at where to find the rim size marked on your rims, how to read those markings, and how to measure them yourself.

Now that you know how to read rim size accurately, you can shop for brand new rims much more easily. Check out the Directory over at carpart.com.au to look for local dealers that will have your next pair of brand-new rims!