

How To Do D-Link Wifi Extender Setup In An Easy Way?

To browse the internet it is very important to have optimal coverage from your wifi router's network. For that, you need to install a wifi extender in your home network. So what is better than a D-Link wifi range extender? In this blog, we will discuss the easiest way to do D-Link Range Extender Setup. You can set up your wifi range extender via two different methods namely; the WPS method and the web browser method.

Easy Instructions For D-Link Wifi Extender Setup Using WPS Method:

- The first and most important step is to locate the D-Link wifi range extender in the same room as your current WiFi router.
- Now, connect the wifi range extender into a functional wall socket.
- After a minute, press the WPS push button on the wifi router device.
- Now, verify whether the LED bulb indicator is green or not.
- The green LED bulb will turn solid green once the wifi router and D-Link wifi range extender are successfully associated.
- The next step is to disconnect the D-Link wifi range extender and relocate it where the signal range was pathetic.

Easy Instructions For D-Link Wifi Extender Setup Using Web Browser Method:

- The first step is to link your D-Link wifi range extender to the PC device using an Ethernet cable.
- On your computing device, unfurl the wireless utility feature.
- After that choose the network name or SSID of your wifi extender and fill in the passphrase.
- Now, launch any internet browser on your PC, and type dlinkap.local in the web address bar
- Another easy way to access the D-Link admin web interface is by using the default gateway address which is 192.168.0.50.
- This will redirect you to the login page for the D-Link wifi extender.

- Enter the needed login credentials in their respective fields and press the login tab.
- After landing on the configuration web page, tap on the 'Setup' tab.
- The next step is to unfurl the D-Link wifi range extender setup wizard and do as instructed.
- Begin with the configuration settings for the wireless extender and security settings of the D-Link wifi range extender.
- Finally, tap on the Finish tab to complete the D-Link wifi range extender setup.
- After completing the setup process, restart the D-Link wifi range extender and then connect with other devices.

Easy Instructions For D-Link Wifi Extender Login:

- Most importantly, place the D-Link wifi extender in an appropriate area.
- Then, associate your PC system to the wifi range extender's network using an Ethernet cable.
- Afterward, connect the D-Link wifi extender into a functional AC wall socket and then turn it on.
- Now you must link your computer or laptop to the extended wifi network.
- Next, enter the URL http://dlinkap.local in the web browser's address field then press the enter key.
- You can also use the default IP address 192.168.0.50 to get into the D-Link Extender's admin web page.
- Here you have to log in using the username and password on the login page and then hit the login tab.

D-Link WiFi Extender Setup On Your Fingertips!

With this, your D-Link wifi range extender setup is now concluded. Now, move ahead and connect it to your wifi-compatible devices. It extends the wifi network to network dead zones uniformly. The <u>D-Link Wifi Extender Setup</u> is quite easy-peasy and convenient to do. Experience the best browsing and surfing time with just a few simple and easy steps.