



Resetting Cricut Explore Air 2 [Simple And Easy Steps]

Using the **Cricut explore air 2** is relatively easy for most of you but sometimes resetting Cricut explore air 2 is necessary to fulfill your design project's needs. It's an excellent rule to update your work constantly.

Resetting Cricut explore air 2 is as simple as installing it. You have to follow some steps, and your work will be done.



Resetting Cricut Explore Air 2

As you know, the Cricut machine is user-oriented. It means that even a complex process that would take an hour in the past can be completed in less than 10 minutes. When you get your Cricut machine, you can't design the same type of project every time.

You ought to know the resetting Cricut explore air 2 process, if you want to become a perfect designer.

Step-by-step Process to Resetting Cricut Explore Air 2

Step 1: You must hold the button below the main menu. At the same time, hold down the button above the menu and the power button. You ought to have to press all the three-button at the same time until and unless you can see a different rainbow screen appear.

Step 2: As you see the rainbow screen, release the button.

Step 3: You must follow the on-screen prompts to resetting **Cricut explore air 2** as per your preference.

Step 4: It does not end here. Turn on the machine without loading the cartridge. You also have to reset the Cricut connection.

Step 5: Once you finish the above process, change the gray dials to the lowest settings. You can easily see that there are two dials on the left side of the machine and one dial on the right side.

Step 6: If you can see the machine communication error, resolve the issue. To determine the problem, go to your smartphone setting and unpair all the previous Cricut machines.

Step 7: To resetting **Cricut explore air 2**, re-pair your machine with your smartphone.

Step 8: With the new connections, you can easily send design from the Design software mobile app to the machine as you did previously.

Step 9 – Download and install the android app – Design space and try to send your design to the machine.

Step 10: Your resetting **Cricut explore air 2** is done successfully, and it's ready to create a fantastic design.

Maintenance Tips for Cricut Explore Air 2

Resetting **Cricut explore air 2** is necessary to make a unique design. In the same way, maintenance is also essential for your machine. Like any other machine available in your home, **Cricut Explore Air 2** also needs good care.

The Cricut machine comes with a user manual, so if you are unsure how to reset it, you can refer to this manual. It helps you to Resetting **Cricut explore air 2**.

Here, we will discuss some of the maintenance tips necessary for your machine. These maintenance tips enhance your Cricut machine performance, efficiency, and durability.

Cleaning

We recommend you clean your machine once or twice per month. The frequency of the cleaning also depends on how often you use your device. Removing the dust particles on the surface and inside will ensure that your cutting will be perfect.

Up To-date Android apps – Design space

Like any other software on your mobile phone, the android app – design space is continuously updated. It enhances the performance of your work.

Most of the issues are resolved just by updating the apps.

To keep your app up to date, you can turn on the notification. Whenever a new update is available, you can get a message. With just one click, you can enhance the performance of your software.

Re-calibrate your machine

You can also re-calibrate your **Cricut machine**. The Cricut explore air two devices allow its user to calibrate for print and cut. This process will ensure that you can get a flawless cut from your machine.

If you want to use a rotary blade or a knife blade, you can also calibrate before starting.

Go to the **Cricut design space** homepage. Here, you can find the menu button in the top left corner. From the dropdown menu, select the Calibrate options. You can see the three options on the menu.

Follow each step that displays on your screen for a successful process.

Remove old project files

Once your design is completed, you should remove the old project files. It does not mean keeping all the old files that are no longer used.

If you keep all the files, you may accidentally send the whole design files to the machine, and the outcome is wastage of materials.

Go to the **Cricut design space** homepage to delete the file and click on my projects. After that, click view all. Here, you can see the list of all the projects. Select those projects which are no longer used and then delete them. Make sure you select the correct file because this process is irreversible.

Cleaning the cutting mat

It's necessary to clean the mat regularly for better results. We recommend you clean your mat after every two to four cuts.

Source:- [Cricut.com/setup](https://cricut.com/setup)